31/08/2001

SUPPLY PIPING STEERING GEAR

- INJECTION ES9J4, LEFT HAND DRIVE, UNVARIABLE POWER STEERING, PRESS PUMP 6+2 + NON-SINKING



04/97 M3938080

M3938080

				HIGH PRESS PIPE
2		4023 J3	01	
3		4023 E8	01	
4		4020 7W	01	PIPE SET
5		96 085 783	01	PIPE LINING TUBE 6,35
6		5280 L4	01	PIPE 4WAY UNION
7		4015 04	01	PRESSURE LIMITE
8		4048 H5	02	HYD OIL O-RING 14--1,9
				OIL PRES SWITCH
9		4015 03	01	REP VIOLET TO O 03029
		4015 09	01	20 BARS REP VIOLET FROM O 08030

31/08/2001

SUPPLY PIPING STEERING GEAR



M3938050

4	.../...	5280 47	01	**LINE BRACKET** OR TURBO DIESEL XUD11BTE OR TURBO DIESEL DK5ATE TO O 06915
		5280 G5	01	- INJECTION XU10J4R, 5 DOOR SALOON, BVA FROM O 06916 OR TURBO INJECTION XU10J2TE, 5 DOOR SALOON, BVA FROM O 06916 OR TURBO DIESEL XUD11ATE, 5 DOOR SALOON FROM O 06916 OR TURBO DIESEL DK5ATE FROM O 06916
5		96 085 783	02	**PIPE LINING** TUBE 6,35

31.08/2001

SUPPLY PIPING STEERING GEAR



07/94 M3938050

M3938050

	4023 98	01	**HYDRAULIC TUBE** -INJECTION XU10J4R, BVM, 5 DOOR ESTATE FROM O 07084
	4023 55	01	-INJECTION XU10J4R, BVA, WITHOUT AIR CONDITIONING TO O 07083
	4023 56	01	-INJECTION XU10J4R, BVA, AIR CONDITIONING TO O 07083
	4023 99	01	-INJECTION XU10J4R, BVA FROM O 07084
	4023 57	01	-TURBO DIESEL DK5ATE, WITHOUT AIR CONDITIONING
	4023 58	01	-TURBO DIESEL DK5ATE, AIR CONDITIONING
	4023 72	01	-BVA, WITHOUT AIR CONDITIONING, TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE
4023 73 RP 4023 J6		01 01	*-BVA, AIR CONDITIONING:* *TURBO DIESEL XUD11ATE* *OR TURBO DIESEL XUD11BTE TO O 07299*
	4023 J6	01	-TURBO DIESEL XUD11BTE, BVA, AIR CONDITIONING FROM O 07300
	4023 74	01	-TURBO DIESEL XUD11BTE, BVM, WITHOUT AIR CONDITIONING
	4023 J5	01	-TURBO DIESEL XUD11BTE, BVM, AIR CONDITIONING
	4023 76	01	-TURBO INJECTION XU10J2TE, BVM
	4023 77	01	-TURBO INJECTION XU10J2TE, BVA
	5280 47	01	**LINE BRACKET** - INJECTION XU10J4R, 5 DOOR SALOON, BVM OR INJECTION XU10J4R 5 DOOR ESTATE OR INJECTION XU10J4R, 5 DOOR SALOON, BVA TO O 06917 OR TURBO INJECTION XU10J2TE, 5 DOOR SALOON, BVM OR TURBO INJECTION XU10J2TE, 5 DOOR ESTATE OR TURBO INJECTION XU10J2TE, 5 DOOR SALOON, BVA TO O 06917 OR INJECTION ZPJ OR INJECTION ZPJ4 OR DIESEL XUD11A OR TURBO DIESEL XUD11ATE, 5 DOOR SALOON TO O 06917 OR TURBO DIESEL XUD11ATE, 5 DOOR ESTATE

.../...

11/08/2001

SUPPLY PIPING STEERING GEAR

- LEFT HAND DRIVE, UNVARIABLE POWER STEERING, PRESS PUMP 6+2 + NON-SINKING EXCEPT INJECTION ES8J4



M3938050

			HYDRAULIC TUBE
1	**4023 78**	01	- INJECTION XU10J4R, 5 DOOR SALOON, BVM OR INJECTION XU10J4R, 5 DOOR SALOON, BVA TO O 06917 OR TURBO DIESEL XUD11ATE, 5 DOOR SALOON OR TURBO DIESEL XUD11ATE, 5 DOOR ESTATE OR TURBO INJECTION XU10J2TE, 5 DOOR SALOON, BVA TO O 06917 OR TURBO INJECTION XU10J2TE, 5 DOOR ESTATE, BVA OR TURBO DIESEL DK5ATE TO O 06828
	4023 70	01	DIAM 6.35-L 1117 -TURBO DIESEL DK5ATE FROM O 06829 TO O 06915
	4023 93	01	- INJECTION XU10J4R, 5 DOOR SALOON, BVA FROM O 06916 OR TURBO INJECTION XU10J2TE, 5 DOOR SALOON, BVA FROM O 06916 OR TURBO DIESEL XUD11ATE, 5 DOOR SALOON FROM O 06916 OR TURBO DIESEL DK5ATE FROM O 06916
	4023 59	01	- INJECTION XU10J4R, 5 DOOR ESTATE OR TURBO INJECTION XU10J2TE, BVM OR TURBO DIESEL XUD11BTE
			PIPE SET
2	*95 666 903*	01	*-EXCEPT TURBO DIESEL DK5ATE*
	RP 4020 7W	01	
	4020 7W	01	-TURBO DIESEL DK5ATE
			HYDRAULIC TUBE
3	**4023 52**	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON, WITHOUT AIR CONDITIONING TO O 07083
	4023 97	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON FROM O 07084
	4023 51	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON, AIR CONDITIONING TO O 07083
	4023 54	01	-INJECTION XU10J4R, BVM, 5 DOOR ESTATE, WITHOUT AIR CONDITIONING TO O 07083
	4023 53	01	-INJECTION XU10J4R, BVM, 5 DOOR ESTATE, AIR CONDITIONING TO O 07083

.../...

31/08/2001

SUPPLY PIPING STEERING GEAR



07/94

M3938010

M393s010

- LEFT HAND DRIVE, 5 SUCKERS PRESS PUMP

1	*96 069 111*	01	*HYDRAULIC TUBE DIAM 6.35-1075*
	RP 4023 59	01	
2	*95 666 903*	01	*PIPE SET*
	RP 4020 7W	01	
			HYDRAULIC TUBE
3	**4023 32**	01	DIAM 4,5 L = 1323 -BVM: INJECTION XU10J2 OR DIESEL XUD11A
	4020 0Z	01	DIAM 4,5 L = 1469 -BVM: TURBO INJECTION XU10J2TE OR TURBO DIESEL XUD11ATE
	96 069 569	01	DIAM 4,5-1090 -BVA: TURBO INJECTION XU10J2TE OR TURBO DIESEL XUD11ATE
	96 091 438	01	DIAM 4,5-908 -INJECTION ZPJ, BVA
4	**96 153 495**	01	**HYD PIPE UNION** 2X2 VOIES
5	**96 085 783**	01	**PIPE LINING** TUBE 6,35

31/08/2001

SUPPLY PIPING STEERING GEAR



M39-8100

- RIGHT HAND DRIVE, 5 SUCKERS PRESS PUMP

1	4023 20	01	**HYDRAULIC WIRE**
			HYDRAULIC TUBE
2	4023 34	01	- INJECTION ZPJ OR INJECTION ZPJ*
3	4023 32	01	DIAM 4,5 L = 1323 -BVM: INJECTION XU10J2 OR DIESEL XUD11A
	4020 0Z	01	DIAM 4,5 L = 1489 -BVM: TURBO INJECTION XU10J2TE OR TURBO DIESEL XUD11ATE
	96 069 569	01	DIAM 4,5-1090 -BVA: TURBO INJECTION XU10J2TE OR TURBO DIESEL XUD11ATE
	96 091 438	01	DIAM 4,5-908 -INJECTION ZPJ, BVA
4	95 666 904	01	**PIPE SET**
5	96 085 783	01	**PIPE LINING** TUBE 6,35
6	96 153 495	01	**HYD PIPE UNION** 2X2 VOIES
			UNION-SCREW
7	96 071 474	01	DIAM 14X100
8	96 071 475	01	DIAM 12X100
9	4048 H3	02	**HYD OIL O-RING** 14--1,9
10	6917-A5	02	**CAPSCREW**-DIAM 6X100-16

31/08/2001

SUPPLY PIPING STEERING GEAR



[02/97] M3938150

M3936150

- RIGHT HAND DRIVE, UNVARIABLE POWER STEERING, PRESS PUMP 6+2 + NON-SINKING EXCEPT INJECTION ES9J4

				HYDRAULIC TUBE
2		4023 60	01	- INJECTION XU10J4R, 5 DOOR ESTATE OR TURBO INJECTION XU10J2TE OR TURBO DIESEL XUD11BTE
		4023 79	01	- INJECTION XU10J4R, 5 DOOR SALOON OR TURBO DIESEL DK5ATE OR TURBO DIESEL XUD11ATE
3		4023 78	01	-TURBO INJECTION XU10J2TE, BVM
		4023 77	01	-TURBO INJECTION XU10J2TE, BVA
		4023 52	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON, WITHOUT AIR CONDITIONING TO O 07083
		4023 51	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON, AIR CONDITIONING TO O 07083
		4023 97	01	-INJECTION XU10J4R, BVM, 5 DOOR SALOON FROM O 07084
		4023 54	01	-INJECTION XU10J4R, BVM, 5 DOOR ESTATE, WITHOUT AIR CONDITIONING TO O 07083
		4023 53	01	-INJECTION XU10J4R, BVM, 5 DOOR ESTATE, AIR CONDITIONING TO O 07083
		4023 98	01	-INJECTION XU10J4R, BVM, 5 DOOR ESTATE FROM O 07084
		4023 55	01	-INJECTION XU10J4R, BVA, WITHOUT AIR CONDITIONING TO O 07083
		4023 56	01	-INJECTION XU10J4R, BVA, AIR CONDITIONING TO O 07083
		4023 99	01	-INJECTION XU10J4R, BVA FROM O 07084
		4023 57	01	-TURBO DIESEL DK5ATE, WITHOUT AIR CONDITIONING
		4023 58	01	-TURBO DIESEL DK5ATE, AIR CONDITIONING
		4023 72	01	-BVA, WITHOUT AIR CONDITIONING. TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11STE
		4023 73	01	-BVA, AIR CONDITIONING:
	RP	4023 J6	01	TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE TO O 07658

.../...

31/08/2001

SUPPLY PIPING STEERING GEAR



[02/97] M3938150

M3938150

			HYDRAULIC TUBE
	4023 J6	01	-TURBO DIESEL XUD11BTE, BVA, AIR CONDITIONING FROM O 07659
	4023 74	01	-TURBO DIESEL XUD11BTE, BVM, WITHOUT AIR CONDITIONING
	4023 J5	01	-TURBO DIESEL XUD11BTE, BVM, AIR CONDITIONING
			PIPE SET
4	4020 8W	01	-TURBO DIESEL DK5ATE
	95 666 004	01	-EXCEPT TURBO DIESEL DK5ATE
5	96 085 783	01	**PIPE LINING** TUBE 8,35
6	5280 47	01	**LINE BRACKET**

31/08/2001

SUPPLY PIPING STEERING GEAR

- INJECTION ES9J4, RIGHT HAND DRIVE, UNVARIABLE POWER STEERING, PRESS PUMP 6+2 + NON-SINKING



[04/67] M3938180

M3938180

			HIGH PRESS PIPE
2	4023 E9	01	
3	4023 E8	01	
4	4020 8W	01	PIPE SET
5	96 085 783	01	PIPE LINING TUBE 6,35
6	5280 L4	01	PIPE 4WAY UNION
7	4015 04	01	PRESSURE LIMITE
8	4048 H5	02	HYD OIL O-RING 14--1,9
			OIL PRES SWITCH
9	4015 03	01	REP VIOLET TO O 08029
	4015 09	01	20 BARS REP VIOLET FROM O 08030

31/06/2001

SUPPLY PIPING STEERING GEAR

- DIRAVI



11.98 M393.8200

M3938200

			HYDRAULIC TUBE
1	**4023 01**	01	DIAM 4,5 L=696
2	**4023 19**	01	
3	**96 025 409**	01	DIAM 6,35-1230
4	**96 024 704**	01	DIAM 4,5-550
5	**4023 37**	01	
6	**4023 02**	01	DIAM 4,5 L=578
7	**96 025 403**	01	DIAM 6,35-825
8	**4023 36**	01	**PIPE 4WAY UNION**
			PIPE LINING
9	**96 085 783**	02	TUBE 6,35
10	**96 085 784**	02	TUBE 4,5